



Unit B Grovelands Estate, Longford Road, Exhall, Coventry CV7 9ND
Tel: +44 (0)24 7664 5999 | Fax: +44 (0)24 7664 4081
Email: ppickering@coventrytoolholders.co.uk | Web: www.ctl-centreline.com
A Member of Coventry Engineering Group

EASY TO OPERATE

A component is located in the fixture which is mounted on a bridge plate. The component is then pushed manually onto the taps which engage and draw the part onto the taps. When they have reached their controlled depth, a limit switch on the guide bar reverses the motor and the part is fed off the taps.



AUTOMATIC FEED OPTION

To further enhance the Rapidtap's capability we can also offer a fully automatic cycle with bowl or magazine feed via loading tracks. After completion of the loading and tapping operations, the component is automatically discharged into the unloading tray. Automatic feed allows one operator to look after several machines.

